




AXIS Consortium: Crystal Actuator Applications



A X I S Consortium

- Critical DOD system demonstrations to show merits of single crystals over other smart materials technologies
- Crystal component manufacturing optimization and cost reduction
- Crystal characterization and modeling



Crystal Component and Stack Manufacturing; Bridgman & TGG Development



Device Characterization and Modeling



Micro-actuators for Commerical Applications



Tonpilz Arrays for Topedo Sonar



Active Flow Control; Stacks for Smart Structures

Government Participants



Crystal/Cymbal Arrays






Crystal Characterization



AFC; Patch Actuators


Flux Growth of PZN-PT

- Irregular growth shape & size limitations
- Most developed technique
- Largest size: 25 mm x 15 mm
- Rectangular plates as thin as 4 mils, disks, rings, composites




1-3 crystal composite
(posts are 150 mm square)

Each Crucible Yields One of the Following Cases:



Bridgman Growth of PMN-PT



- **Faster growth rate**
- **Simplified orientation and machining**
- **Reduced cost over flux**
- **Goal: crystals > 2 inches in diameter**
- ***Current crystals are 1 inch in diameter***




Orientation	k_{33}	$s_{33}^E (10^{-12} \text{ m}^2/\text{N})$	d_{33} (pC/N)	K	Fr Cnst (Hzm)
$\langle 100 \rangle$	0.92	68 to 77.5 ⁺	1900 to 2100	6100* to 6800	1640

⁺ $Y_E = 14$ to 15 Gpa, 50% stiffer than PZN-PT crystals

Growth from Hydrothermal PbTiO_3

- **Templated Growth of Grain Oriented Ceramics**
- **Chemically *Homogeneous* Microstructure**
- **Large Scale, Low Cost Seed Production**
- **First Demonstration of Growth from PT Seeds**

Hydrothermal PT Platelets



d_{31} Actuation with Single Crystals


Active Flow Control (Boeing, NASA)

Benders (ACX)

Patch Actuators for Active and Passive Damping (NASA, ACX)


Cymbal Arrays (NRL)

All Require
 d_{31} Mode
 Actuation





Transducer Stack for NUWC Sonar Application

Resonance: $k_{33} = 0.9$





**Improved Performance over
Actuator Stack Due to
Increase in Plate Thickness (1.8mm)
& Reduction in Shim Thickness (0.5 mil)**

NUWC Single Crystal Stack Performance
3.6 mm x 3.6 mm x 9.0 mm 5 active layers



Crystal Actuator Stack



- **Equivalent Strain Response for Bulk Crystal and Stack**
- **Achieved with Reduced Shim Thickness and Increased “Lacyness”**

TRS Goal: Component Cost Reduction

as new manufacturing technologies are developed by TRS

