

# ***Piezoelectric Pump using Innovative Non-Mechanical Valves***

DARPA Contract # DAAH01-99-C-R236

## **SBIR PHASE I**

### **Objectives and scope of Program**

- To demonstrate the feasibility of building high energy density pumps utilizing piezoelectric electromechanical actuation and active non mechanical valves.
- Fabrication of prototype pump and valves
- Proof of concept demonstrations

### **Principal Investigators**

Conal O'Neill  
Dr. Quanfang Chen

Kinetic Ceramics Inc.  
UCLA




**Kinetic Ceramics Inc.**  
*Pioneers in Piezoelectric Technology*

Technical Interchange Meeting  
6/26/2000  
Slide # 1

**UCLA**

# Schedule



**Kinetic Ceramics Inc.**  
Pioneers in Piezoelectric Technology

Technical Interchange Meeting  
6/26/2000  
Slide # 2

**UCLA**

# *Program Responsibilities*

- Kinetic Ceramics Inc. - PRIME
  - Design & fabricate a piezoelectric pump capable of operating to 10kHz. Demonstrate pump operation.
  - Task Completed
- UCLA
  - Demonstrate the bubble valve principle by fabricating valves through Silicon micro machining techniques. Characterize valve performance.
  - Task Completed

# *Major Accomplishments*

- Successful fabrication of bubble valve structures in series / parallel arrays.
- Demonstration of the valve operation under dynamic conditions.
- Valve demonstrated to withstand 100 psi so far.
- Demonstration of pump operation with conventional valves.
- Pump demonstration validates goal of 10cc/sec at 10 kHz is attainable.



# *Lessons Learned & Future Transitions*

- High frequency Bubble Valve Pump concept is viable.
- In a Phase II program, it is proposed to increase the pump energy density two orders of magnitude by integrating the developed Bubble Valve into the pump. Packaging of the Bubble Valve will be addressed.
- The resulting high energy density pump is scaleable and will become available for a multitude of aerospace actuator and control applications.


# *Motivation for Bubble Valve*

- ***Requirement of Compact Actuator Device:***
  - Active materials have fast response, high force and little displacement. To obtain high power density it is desirable to operate at high pressure and high frequency.
- ***Mechanical check valves:***
  - Low frequency response (less than 200 Hz), fatigue and wear especially with high pressure.
- ***Bubble valve:***
  - High frequency response (2k to 30 kHz) and large pressure drop(1MPa to 3GPa), without fatigue and wear.




# *Bubble Valve Driving Mechanism*

- Valve functions by generating/collapsing a bubble that blocks an orifice.
- Explosive nucleation generates huge pressure differentials.
- Shorter heating time produces higher pressure drop (10 MPa).
- Bubble generation time can range between 100 ns and 100  $\mu$ s (frequency >10kHz) .




Bubble valve closed



Bubble valve open

# Bubble Valve Design



Single valve:

Channel size:  $50\mu\text{m}$  in diameter

Opening area:  $A=5 \times 10^{-2} \text{ mm}^2$


Array:

Total opening area required:  $1.7 \text{ mm}^2$

Number of valves required: 866

Overall size: 7.5 mm diameter

Flow rate: 10cc/sec



**Kinetic Ceramics Inc.**

*Pioneers in Piezoelectric Technology*

Technical Interchange Meeting


6/26/2000

Slide # 8


**UCLA**



# *Fabrication of Bubble Valve*




Fabrication process of heater



Top view of fabricated heater



Integrated heaters, circular arrangement



Integrated heaters, rectangular arrangement

- Lithography micromachining method
- Polycrystal silicon microheater
- Integration into an array for large flow rate



**Kinetic Ceramics Inc.**

*Pioneers in Piezoelectric Technology*

Technical Interchange Meeting

6/26/2000

Slide # 9


**UCLA**

# *Summary*

## *Bubble Valve Development*

- Bubble valve designed, fabricated and tested.
- Tested successfully with 100psi differential pressure.
- Frequency response verification limited by video recording equipment. Higher frequency response with similar design demonstrated ( $>10\text{kHz}$ ).
- Integration of bubble valve with PZT pump will be possible once packaging issues are addressed.

# *Test Chamber*




**Kinetic Ceramics Inc.**  
*Pioneers in Piezoelectric Technology*

Technical Interchange Meeting  
6/26/2000  
Slide # 11

**UCLA**

# *Test Setup for Bubble Valve*



- Transparent view chamber with macro view camera
- Water pump to deliver high pressure
- Bubble valves tested under high pressure





**Kinetic Ceramics Inc.**  
*Pioneers in Piezoelectric Technology*

Technical Interchange Meeting  
6/26/2000  
Slide # 12

**UCLA**

# *Bubble Testing*



- Joule heating forms bubble in 10  $\mu$ s.

Single bubble generated on microheater



- Series / parallel heaters form multiple bubbles.
- Bubbles generated under hydrostatic pressure (100psi).

Multiple bubbles generated on microheaters



**Kinetic Ceramics Inc.**

*Pioneers in Piezoelectric Technology*


Technical Interchange Meeting

6/26/2000


Slide # 13

**UCLA**


# Testing of Bubble Valve



Multiple valves




Valve open/closed by bubble



Before pumping

Pumping while heating a bubble,  
valve closed w/pressure wave  
distributed



Test setup



**Kinetic Ceramics Inc.**  
*Pioneers in Piezoelectric Technology*

Technical Interchange Meeting  
6/26/2000  
Slide # 14

**UCLA**



# *Phase I Piezoelectric Pump*



## Specifications:

- Diaphragm Pump
- PZWT100 Stack
- Stack volume: 2 cm<sup>3</sup>
- Stack mass: 17 g
- Mechanical Valves
- Displacement 5 mm<sup>3</sup>




**Kinetic Ceramics Inc.**  
*Pioneers in Piezoelectric Technology*

Technical Interchange Meeting  
6/26/2000  
Slide # 15


**UCLA**

# *Pump Cross Section*





# *Piezoelectric Pump Operation*




**Kinetic Ceramics Inc.**  
*Pioneers in Piezoelectric Technology*

Technical Interchange Meeting  
6/26/2000  
Slide # 17

**UCLA**

# ***Piezoelectric Pump Test Setup***



**Kinetic Ceramics Inc.**  
*Pioneers in Piezoelectric Technology*

Technical Interchange Meeting  
6/26/2000  
Slide # 18

**UCLA**

# ***PH I Pump Performance Tests***

	PH II Design Goal	PH I Actual
Stall Pressure	600 psi	800 psi
Volume / Stroke	1 mm <sup>3</sup>	4.0 mm <sup>3</sup>
Frequency	10kHz	100 Hz*
Flowrate	10 cc / sec	0.4 cc / sec

\*Power supply limitation. Mechanical valves predicted to permit operation to 500 Hz.



**Kinetic Ceramics Inc.**  
*Pioneers in Piezoelectric Technology*

Technical Interchange Meeting  
6/26/2000  
Slide # 19

**UCLA**